

Installation Procedure

Knauf Aquapanel Exterior Cement Boards are designed to be simple and fast to install. Knauf Technical Services are on hand should you have any questions or unusual situations to deal with.

Preparation

1 Use a knife to score the Knauf Aquapanel Exterior on one side so that the mesh is cut. Snap the scored edge and cut through the mesh on the rear side.

For sharp-edged cuts, for example exterior edges, use a hand-held circular saw with a dust extractor or a pendulum jigsaw. To make cut-outs for wiring and pipes, use a jigsaw or keyhole saw.

The diameter of the opening should be approximately 10mm greater than the diameter of the pipe. The remaining gap can be closed with a suitable sealant or sealing strip.

Knauf Aquapanel Exterior can be curved to a radius of 3 metres with a full board or to a 1 metre radius having cut the board into 300mm strips. Bend the Knauf Aquapanel Exterior panel prior to installation. The fine cracks that occur on the board surface will not cause any loss of performance to the final system when finished to a basecoat level.

Fixing Board

2 Apply Knauf Aquapanel Exterior horizontally to members at maximum 600mm centres. Ensure there is a gap of 3–5mm between the boards and that the members are central behind both boards.

When fitting Knauf Aquapanel Exterior, ensure that the vertical joints are centrally aligned to the board below.

When fitting Knauf Aquapanel Exterior around windows and doors ensure that no vertical joints coincide at window and door corners as this may allow moisture ingress.

Use Knauf Aquapanel Maxi Screws to fix the boards to metal members.

Use Knauf Aquapanel Exterior Stainless Steel Screws to fix the boards to the timber members.

Screws should be at least 15mm in from the edge of the Knauf Aquapanel Exterior and spaced at maximum 250mm centres.

Screws should not be over tightened.

Taping and Jointing

3,4 Immediately after installing the Knauf Aquapanel Exterior, protect the framework from weathering by filling all the joints with Knauf Aquapanel Exterior Joint Filler – Grey. Use the Knauf Aquapanel Exterior Joint Filler – Grey to fill the gaps between the board and then spread it over the face of the board ready to take the tape. Immediately embed Knauf Aquapanel Exterior Joint Tape (10cm) or Knauf Aquapanel Exterior Reinforcing

Tape – as specified, centred over all of the joints. Scrape the excess Knauf Aquapanel Exterior Joint Filler – Grey from the Knauf Aquapanel Exterior Tape leaving it just covered.

Cover the screw heads with Knauf Aquapanel Exterior Joint Filler – Grey.

Corners are protected by applying exterior basecoat, then embedding a corner profile in a similar way to the joint tape.

Reinforce window and door corners with extra pieces of reinforcing mesh, cut to size 50 x 30cm, embedded into exterior basecoat as per corner profiles.

Finishing

Refer to installation instructions from the selected/specified render supplier, alternatively:

5,6,7 Cover the entire wall with basecoat to a depth of approximately 5mm.

Using a tile adhesive trowel create a notched layer of basecoat with notch depth of approx 8mm. Return the removed basecoat to the bucket to be reused later.

Embed reinforcing mesh over the entire surface. Overlap the reinforcing mesh by 100mm at edges. Apply a thin coat of basecoat over the mesh and notches just covering the mesh and creating a smooth finish. The finished layer should be approximately 5–7mm thick and the reinforcing mesh should be in the top third of the finished surface. Before continuing with the next steps, allow the basecoat to fully dry.

Exterior Render

8 Render must be applied in accordance with BS EN 13914-4:2005, Code of Practice for External Rendering.


Fully mix the renders before applying them to ensure that the colour is true right through. Apply the chosen exterior finish to each wall area.

The scaffold around the finished wall must be covered to protect from rain or weathering until the finish is fully dry.

Knauf Training Courses

We offer a range of comprehensive training courses at our purpose built training schools to ensure the installer is fully up to speed with the latest techniques and regulations.

Contact 01795 416 259 or visit www.knauf.co.uk/training



1. Scoring Knauf Aquapanel Exterior Cement Board with a knife.



2. Fixing the boards to the background members.



3. Embedding Knauf Aquapanel Exterior Joint Tape.



4. Covering screw heads with Knauf Aquapanel Exterior Joint Filler - Grey.



5. Applying notches within basecoat.



6. Applying reinforcing mesh.



7. Covering mesh with basecoat.



8. Applying finish.